(RETURN) ---- に変更しました。

<Video call screen (Normal view)>



Video call menu

Once a video call has started, the following options will be available.

- End call
- Hold / Resume
- Dial pad
- Mute / Unmute
- (microphone)*
- Start my video / Stop my video
- Full view
- 1) The picture from your contact's communication camera
- (2) The picture from your communication camera
- ③ Video quality indicator
 - (Depending on the network environment.)
- * To change the speaker volume of the unit, use the VOL +/- or MUTE button on the remote control.

<Receiving Skype calls>

You can receive Skype calls even while watching a TV program or video. When you receive an incoming call, a window will appear in the bottom right-hand corner of your screen. Choose between "Video", "Audio", "Decline" or "Hide" and press ENTER.

Incoming c	all	_
Vickie		
	Video	
	Audio	
	Decline	
	Hide	
\$: Select	ок: Enter	

NOTE

- You cannot receive calls when you are signed out of Skype, when your TV is in standby mode, or when the power is off.
- Skype on your TV cannot be activated while using a certain specific function. In that case, please stop using the function.

OTHER USEFUL FUNCTIONS

Skype menu

1 History

- Shows your call history.
- Allows you to call a person displayed in Call History and to accept or block contact requests.

NOTE

• If the time displayed in History is inaccurate, change the setting value from the TV menu (e.g., Menu > Initial Setup > EZ Setup > Location & Time).

2 Profile

Set up the following items.

Edit profile	Edit your profile.
Online status	Change your online status.

3 Settings

Set up the following items.

General settings	Select whether you want to sign in automatically when you enter Skype.
Change password	Change your password.
Video settings	Adjust the privacy settings for video.
Privacy settings	Choose whom you wish to receive calls from.
Block contacts	Set the person who you don't want to hear.